

Sturzpad-Kit TRIUMPH Speed Triple 1050 ('04 - '10)  
Frame Slider Kit TRIUMPH Speed Triple 1050 ('04 - '10)

**Montagehinweise**

Alle vom Motorrad gelösten Schrauben sind gemäß Herstellerangaben wieder zu montieren, oder mit von SW-MOTECH gelieferten Schrauben zu ersetzen. Falls nicht anderweitig definiert, diese Schrauben nach Tabelle anziehen.

<b>M6</b>	<b>9,6 Nm</b>
<b>M12</b>	<b>79 Nm</b>

Gegebenenfalls Schrauben mit flüssiger Schraubensicherung einkleben.

Prüfen Sie nach 50 km alle Verbindungen auf festen Sitz.

SW-MOTECH GmbH & Co. KG  
Ernteweg 8/10  
35282 Rauschenberg  
Germany

Tel. +49 (0) 64 25/8 16 8-00  
Fax +49 (0) 64 25/8 16 8-10

info@sw-motech.com  
www.sw-motech.com

**Mounting Instructions**

SW-MOTECH products should be installed by a qualified, experienced motorcycle technician. If you are unsure of your ability to properly install a product, please have the product installed by your local motorcycle dealer. SW Motech takes no responsibility for damages caused by improper installation.


All screws, bolts and nuts, including all replacement hardware provided by SW-MOTECH, should be tightened to the torque specified in the OEM maintenance manual for your motorcycle. If no torque specifications are provided in the OEM maintenance manual, the following torques may be used:

<b>M6</b>	<b>9,6 Nm</b>
<b>M12</b>	<b>79 Nm</b>

All screws, bolts and nuts should be checked after driving the first 50 km to ensure that all are tightened to the proper torque.

Medium strength liquid thread-locker (i.e., "Locktite") should be used to secure all screws, bolts and nuts.


1 Sturzpad  
Frame Slider



STP.00.590.001

Anzahl/ Pcs. 2

2 Logoplatte  
Logo Plate



LOG.00.000.001

Anzahl/ Pcs. 2

3 Senkkopfschraube  
Countersunk Screw




M3 x 12 DIN 7991

Anzahl/ Pcs. 4

STP.00.590.10000/B


4 Anbaublech  
Mounting Bracket



STP.11.590.003

Anzahl/ Pcs. 2

5 Innensechskantschraube  
Hexagon Socket Screw




FEINGEWINDE  
rechte Seite/right side

M12 x 1,25 x 60 DIN 912

Anzahl/ Pcs. 1

6 Innensechskantschraube  
Hexagon Socket Screw




FEINGEWINDE  
rechte Seite/right side

M12 x 1,25 x 100 DIN 912

Anzahl/ Pcs. 1

7 Distanzbuchse  
Spacer




rechte Seite/right side

Da:25 Di:12,5 h:30

Anzahl/ Pcs. 1

8 Unterlegscheibe  
Washer



A 13 DIN 125

Anzahl/ Pcs. 4

9 Innensechskantschraube  
Hexagon Socket Screw



FEINGEWINDE  
linke Seite/left side

M12 x 1,25 x 35 DIN 912

Anzahl/ Pcs. 1

10 Innensechskantschraube  
Hexagon Socket Screw




FEINGEWINDE  
linke Seite/left side

M12 x 1,25 x 80 DIN 912

Anzahl/ Pcs. 1

11 Distanzbuchse  
Spacer




linke Seite/left side

Da:20 Di:12,5 h:10

Anzahl/ Pcs. 1


12 Adapterplatte  
Adapter Plate



STP.00.590.007


Anzahl/ Pcs. 2

13 Innensechskantschraube  
Hexagon Socket Screw




M6 x 45 DIN 912

Anzahl/ Pcs. 4



Schritt  
Step 1



Schritt  
Step 2

INFORMATION

Verschrauben Sie Anbaublech (4) zunächst auf der rechten Fahrzeugseite, wie in **Schritt 1** gezeigt. Ziehen Sie alle Schraube an. Achten Sie dabei auf das vom Hersteller vorgeschriebene Anzugsmoment.

Führen Sie nun den Montageschritt auch auf der linken Fahrzeugseite durch. Benutzen Sie die für diese Seite vorgesehenen Teile (siehe Stückliste) analog zur rechten Seite. Verschrauben Sie nun die restlichen Teile, wie in **Schritt 2** dargestellt.

Fasten the mounting bracket (4) first on the right side of the motorcycle, as shown in **step 1**. Then tighten all screws. Pay attention to the manufacturer's specified torque. Now attach the mounting bracket (4) at the left side, following the same procedure. Make sure to use the appropriate (left/right) parts for each side. Then attach the parts shown in **step 2**.